

HYUNDAI
ELECTRONICS

VEGA CONTROLLER

HYU-AC-TACVFAX001

USER MANUAL

CONTROLLER



Quick Installation Guide

Please read this guide first for correct installation and retain it for future reference. The information in this guide has been authenticated at the time of publication. However, Hyundai reserves the right to make changes in product design and specifications without prior notice.

Copyright

All rights reserved. No part of this document may be copied or reproduced in any form or by any means without the prior written consent of Hyundai.

Warranty

Limited Warranty. Valid only if primary protection is provided, mains supply is within limit and protected, and environment conditions are maintained within product specifications. Complete warranty statement is available on our website:

Know Your Controller

Figure1: Front View




Figure2:
Bottom View





Figure3: Rear View



What Your Package Contains

- COSEC VEGA Controller Unit
- Mounting Plate with screw M3/6
- 2 Screws M5/25
- 2 Screw Grips
- Power Supply Cable (with DC Jack)
- Power Adaptor 12VDC,2A
- Exit Switch Cable
- EM Lock Cable
- Ethernet Cable with RJ45 Plug
- Auxiliary I/O Cable
- Quick Installation Guide

Exit Switch cable, EM Lock cable, External Reader Cable and Auxiliary I/O Cable are not in the package of FAXQE.

WARNING

- Installation and servicing should be done only by a qualified technician.
- There are no user-serviceable parts inside.
- Opening or removing the device cover may result in electric shock or exposure to other hazards.
- Use this product only for the purpose for which it was designed.


Things You Will Need

- A Power Drill
- A wire Stripper
- A screw driver set
- Insulation tape
- Access to Server application to configure controller on Server.
- A stand-alone computer with a web-browser to change the network settings of controller.

Inserting Card Personality Module

1. Remove the back cover of your device by removing all screws as shown in Figure 4.


2. Hold the Card Personality Module with the smooth surface towards you, and the narrower end facing down as shown in Figure 5.



3. Lower the module in this position into the CPM slot as shown in Figure 6.

4. Press the free end of the module inwards with your fingertips to lock it in place as shown in Figure 7.

5. Replace the back cover as shown in Figure 8.




Technical Specification


Specification Parameters	FAX	CAX	FAXQ	FAXQE
Sensor	Yes	No	Yes STQC Certified	Yes STQC Certified
Credential Support	Card, Pin and Finger	Card and Pin	Card, Pin and Finger	Card, Pin and Finger
User Capacity		50,000		
Type of Card	EM Prox, HID Prox, HID iClass & Mifare		HID iClass & Mifare	
USB	1 USB for Data Transfer and for 3G-4G dongle			
Communication Port	Ethernet, Wi-Fi, Mobile Broadband (3G-4G)			
Reader Interface Types	RS232 and Wiegand		No	
Reader Power Output	Internal 12 VDC @ 0.2A		No	
Door Lock Relay	Relay SPDT, FormC, 1A@ 30 VDC		No	
Door Lock Power	Internal 12VDC @ 0.5A or External		No	
Auxiliary Outputs Relay	Relay SPDT, FormC, 1A@ 30 VDC		No	
Input Power	12 VDC @2A			
Built in POE	IEEE 802.3 af Class ; Max 12W		No	
Built in Wi-Fi		Yes		
Battery Backup	No Internal battery backup, External Through PSBB			
Operating Temperature	0°C to +50°C			

Pre-Installation Safety Instructions


1. Do not install the device in extremely hot temperature or under direct sunlight on turnstile or at extra bright places. This may affect the LCD and finger print sensor of device. You can do indoor installation or on the turnstile under the roof as shown in Figure9.



5. Do not install the device in outdoor areas which may be exposed to rain, cold and dust. You can do indoor installation or on the turnstile under the roof as shown in Figure10.



2. You can mount the device on a flat surface such as a wall or Elevator, close to the access point (door) with surface wiring or concealed wiring as shown in Figure11.



3. Recommended height from ground level is upto 4.5 feet.

- 4 Do not install on unstable surfaces, near volatile inflammable materials, areas where volatile gas is created, where ferromagnetic field or noise is induced, where static is created, such as desks made of plastics, carpets.

For Inquiries, Please Contact:

Security Shop
Vladimira Popovica 6/6/A606
11070 Novi Beograd, Serbia
Tell +381 11 318 68 68
office@securityshop.rs